

## Pressure Gauge Type PGA

Note: The following steps MUST be taken to ensure the correct long-term function of this pressure gauge.

### Installation Instructions for 63mm gauges with black plug.

After Installation of the pressure gauge:

1. Pierce a small hole in the black plug, or cut the top off the black nipple which is at the top of the gauge.

### Installation Instructions for 63mm gauges with shipping screw.

After Installation of the pressure gauge:

1. Remove the shipping screw at the top of the gauge.
2. Replace the shipping screw with the blow-out assembly (supplied).

### Installation Instructions for 100mm and above gauges.

After Installation of the pressure gauge:

1. Move the Yellow Flag to the open position.



**Note for all gauges:** DO NOT under any circumstances remove the rubber diaphragm or plug from the top of the gauge. The gauge Breather Plug orientation must be in an upright position.

The process connection thread should be prepared with a suitable thread sealant, to prevent leaking of the process fluid. A spanner must be used to tighten the gauge to the process.

If the gauge is subjected to vibration or shock, consider remote mounting the instrument via capillary or impulse line.

Do not hand tighten by using the case body of the gauge. Failure to do any or all of the above could affect correct gauge performance and will void warranty.