

Thermowell Type TTW

Installation.

To fit, drill or cut a 32mm hole the tank or pipe wall. Fillet weld both sides of the thermowell into the process for a sanitary connection.

Note: When inserting temperature sensor probes, coat first with a heat transfer compound before fitting into thermowell.

